

IT ISTRUZIONI PER TELAI CON DROPOUT UDH _ PAG. 2

EN INSTRUCTIONS FOR FRAMESETS WITH UDH DROPOUT _ PAG. 4

ISTRUZIONI DI ASSEMBLAGGIO DEL KIT BIKE-PACKING

PER TELAI CON DROPOUT UDH

1 Rimuovere il bloccaggio del forcellino UDH



2 Sostituirlo con il terminale incluso nel kit bikepacking



IMPORTANTE

Applicare del frenafili ad alta resistenza prima di fissare il tappo terminale al forcellino



3 Inserire il perno posteriore insieme alle 2 rondelle in dotazione. Questo è fondamentale per evitare che si crei del gioco tra i componenti



Nota: Non è possibile installare il kit bikepacking su bici allestite con deragliatore posteriore Sram T-type, ad esempio con gruppo Sram Rival E1

CODICE COLORE	IMMAGINE	FORCELLINO	CODICE KIT BIKEPACKING
C6 GREY, YELLOW GLOSSY		DISEGNO WILIER TRIESTINA	KBP001
C7 LIME, BLACK GLOSSY		DISEGNO WILIER TRIESTINA	KBP001
C8 BLACK, PURPLE MATT		DISEGNO WILIER TRIESTINA	KBP001
C9 BOTTLE GREEN GLOSSY		STANDARD UDH	KBP003
C10 STONE DARK GLOSSY		STANDARD UDH	KBP003

BIKEPACKING KIT ASSEMBLY INSTRUCTIONS

FOR FRAMESETS WITH UDH DROPOUT

1 Remove the UDH dropout bolt



2 Replace it with the end cap that comes with the kit



IMPORTANT

Apply some high-strength thread locker to fix the end cap onto the dropout



3 Insert the rear through axle along with its 2 washers that come with it, this is crucial in order to avoid any kind of play



Note: It is not possible to mount the bikepacking kit on bikes with Sram T-type rear derailleurs setups, e.g. Sram Rival E1

COLOR CODE	IMAGINE	DROPOUT	KIT BIKEPACKING CODE
C6 GREY, YELLOW GLOSSY		PROPRIETARY WILIER TRIESTINA	KBP001
C7 LIME, BLACK GLOSSY		PROPRIETARY WILIER TRIESTINA	KBP001
C8 BLACK, PURPLE MATT		PROPRIETARY WILIER TRIESTINA	KBP001
C9 BOTTLE GREEN GLOSSY		UDH STANDARD DROPOUT	KBP003
C10 STONE DARK GLOSSY		UDH STANDARD DROPOUT	KBP003

