



**JENA**  
HYBRID**1**

Remove the fork and the handlebar from Jena Hybrid in order to allow the following assembly operations.  
Remove the metal plates on the upper part of the down-tube.

**2**

Pull out, from the lower hole of the head tube, the cable connecting the battery to the iWoc button, that are still connected together.

**3**

Disconnect the two cables (battery and iWoc) so that they are loose.

**4**

Connect the battery cable to the corresponding one of the ANT+ conversion kit (B).



2

WILIER PEDIA 2021

E-GRAVEL COLLECTION

5



Connect the iWoc cable to the corresponding one of the ANT+ conversion kit (A).

6



Insert the ANT+ conversion kit inside the down-tube through the lower hole of the head tube.  
If necessary, wrap the kit with some plastic material to avoid noises.

