

# **JLEMA** **HYBRID**

ENG

**ASSEMBLY INSTRUCTIONS – BATTERY**

1



Remove the metallic pieces from the downtube

2



Pass a metallic guide through the side hole of the downtube until the bb.

3



Connect the extremity of the battery/iwoc cable to the metallic guide.

4



Slide the battery inside the downtube

5



Pull out the cable fixed to the metallic guide through the side hole. Fix the battery to the frame. Screw the iwoc button to the holder with the metallic ring.

6



Connect the battery cable to the iwoc

7



Place the connection junction inside the downtube.



**JENA**  
HYBRID

8



Close the side hole with the two closing metallic plates.

9



Close the bb shell cover

10



Assembly the bike as a normal jena. Once that the handlebar is compacted, fix the iwoc holder to the handlebar.



4

WILIERPEDIA 2020

ROAD COLLECTION